



ELECTRALIGHT RECHARGEABLE COB MULTI ANGLE WORK LIGHT













GENERAL INFORMATION

Thank you for purchasing a BlueSpot product, you can find further information on our range at www.BlueSpot.uk.com. Please ensure that you are using the product correctly and that all guidance and cautions are followed in accordance with the instructions. Please retain these instructions for future reference.

SAFE USE

Please make sure that you read these instructions carefully in order to avoid injury when using the work light. Follow all health and safety rules and regulations. If in doubt and available please contact a more knowledgeable source.

DO NOT use if damaged.

- BE AWARE this product is not waterproof.
- ALWAYS check the work light for any damage before use. Check for damage to the plug, cable, lens or light casing. If light is damaged do not use as this may cause damage to property or cause injury.
- ALWAYS inspect the power supply cables and plugs for wear or damage before using the work light. Ensure all the connections are secure.
- ALWAYS check the voltage rating on the work light suits the power supply that you are going to use. Check the plug is fitted with the correct fuse.
- ALWAYS dress appropriately and wear the correct PPE equipment if required.
- ALWAYS ensure the work light is disconnected from the power source when not in use.
- ALWAYS ensure the work light has been turned off and disconnected from the power supply before performing any maintenance or storing.
- Before storing the work light ensure that it has cooled down completely and is dry. Store the work
 light in a cool dry area that is out of reach of children.
- Position the work light where it is not likely to be knocked or cause a hazard while working.
- Maintain the lamp in good and clean condition for best and safest performance.
- Keep the work area clean and uncluttered.
- Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- Keep children and unauthorised persons away from the work area.

SAFE USE (CONTINUED)

- Ensure the work light is fully charged before initial use.
- DO NOT turn the work light on when it is being charged.
- DO NOT allow children to use the work light.
- DO NOT use the work light in damp or wet locations.
- DO NOT move the lamp whilst it is being charged.
- **DO NOT** leave the battery discharged. Always fully recharge the battery straight away before storing. Recharge the battery at least twice a year if not in use.
- NEVER attempt to open and modify the battery pack on the work light.
- If the electrolyte in the battery cells gets onto your skin, make sure you wash your skin with soap and water immediately. If it gets into your eyes, rinse thoroughly with cool water and seek immediate medical attention.
- NEVER direct the light into yours, another person's or animals eyes. This could cause eye damage

INTRODUCTION

The Electralight Rechargeable Multi Angle Work Light is ideal for professional users. The ultra-bright COB light features a 2 phase switch to save energy. The main COB work light operates at 300 lumens in the high energy mode and the top of the torch body also features a 50 lumen torch. The light features two heavy duty magnets on the base, a hook on the rear as well as a large magnet on the rear. The light is also adjustable through 180° for even greater hands free usability. Integrated lithium ion battery and charging base with charge state indicator for quick and easy power when you need it.



SPECIFICATIONS

Model	65308
Battery	18650 3.7V 1800mAh Rechargeable Li-ion battery
Plug	BS plug
Power Source	100-240V AC,50/60Hz
Charging Time	3.5 - 4 hours
Operating Time	2.5 to 3 hours operating time
IP Rating	IP20
Lumen Output	300 lumens – main COB work light 50 lumens – torch on top of body
Energy Saving	2 phase energy saving function
Input Voltage	5V DC
Dimensions	8.5x7.2x38cm
Weight	336g



OPERATION

The work light comes complete with a charging base, charging wire, and plug as well as a travel adapter. Ensure the work light is fully charged before initial use.

CHARGING THE WORK LIGHT WITH THE CHARGING BASE

- 1. Connect the charging lead to the charging base.
- 2. Fit the work light securely into the charging base.
- 3. Plug into the power supply and turn on. A red light will appear on the back of the work light to show it is charging.
- 4. When the work light is fully charged the indicator light will turn green.
- 5. Turn off the power supply and remove the work light from the charging base.

CHARGING THE WORK LIGHT WITH THE TRAVEL ADAPTER

- 1. Connect the charging lead to the travel adapter.
- 2. Plug the charging lead into the back of the work light.
- 3. Plug the travel adaptor into the power supply and turn on. A red light will appear on the back of the work light to show it is charging.
- 4. When the work light is fully charged the indicator light will turn green.
- 5. Turn off the power supply and remove the charging lead from the back of the work light.

OPERATING THE WORK LIGHT

When the work light has been charged using either method above, please follow the steps below for operating the work light.

- 1. Switch the light on using the power button on the front of the light.
- 2. For hands free use the light may be suspended by the hanging hook or attached to a magnetic surface by the magnet on the bottom or back of the work light.
- **NEVER** point the light in yours or somebody else's eyes as this could cause damage to the eyes.

CLEANING & MAINTENANCE

ALWAYS ensure the work light is turned off and is not connected to the power supply when you are cleaning or performing maintenance.

Clean the torch by wiping with a damp cloth.

NEVER use solvents or abrasives to clean the work light.

ELECTRLIGHT

STORAGE

ALWAYS ensure the work light is disconnected from the power source when not in use.

Before storing the work light ensure that it has cooled down completely and is dry. Store the work light in a cool dry area that is out of reach of children.

DISPOSAL

Do not dispose electrical products together with household waste. Please use the correct recycling facilities. If unsure of correct recycling, ask your local authority or retailer for advice.

Contact your local waste disposal authority for information on how to correctly dispose of tools.

WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

ENVIRONMENTAL PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids

according to local regulations.



CONTACT

Find out more about the BlueSpot Lifetime Guarantee at www.BlueSpot.uk.com Tel: 0800 093 0115 / Email: sales@bluespot.uk.com Orme Business Centre, Greenacres Road, Oldham, OL4 3NT